



product data

## Product: Disinfect-All

Date: June 2011

CI/SfB 125	(2-)	(W7)
Common Arrangement C40/J30/J31/P22		

A specialist cleaner for ClearShield Anti-Microbial Glass™.

### 1. Uses

Effective multi-purpose surface cleaner and disinfectant, proven to have anti-microbial properties and compatible with ClearShield Anti-Microbial Glass™.

### 2. Benefits

- Highly effective
- Helps promote an anti-microbial surface
- Requires no rinsing
- Easy to apply
- Disinfects viruses such as hepatitis B and HIV

### 3. Disinfection

- Hepatitis B and HIV, contact time: 1 minute
- MRSA resistant to PM, PEM and PELKM, contact time: 1 minute
- General Disinfection contact time: 1 minute (tested to EN 1040)

### 4. Physical Properties

Blue, pleasant-smelling liquid.  
Non-flammable.

### 5. Pack Sizes

10 x 500ml trigger spray bottles.

### 6. Dilution

Do not dilute.

### 7. Coverage Rates - Typical

40-50 m<sup>2</sup>/litre.

### 8. Handling Precautions

Avoid contact with eyes and prolonged contact with skin.

### 9. Application Instructions

Recommended as a specialist cleaner, to be used when required to maintain the properties of ClearShield Anti-Microbial Glass™.

- Spray onto a clean, soft cloth and wipe evenly onto the surface.
- Polish dry with a clean, soft and dry cloth.

### 10. Storage & Shelf Life

Store in a cool environment in its original container. Unlimited shelf life for unopened containers.

### 11. Health & Safety

Classified as non-hazardous. If necessary, consult the relevant Safety Data Sheet available from Ritec on request.

### 12. Further Information

Wash any spillages with a cloth.



### Important Note

Ritec's products are guaranteed against defective materials and manufacture and are sold subject to its Terms & Conditions of Sale, copies of which may be obtained on request. Whilst Ritec endeavours to ensure that any advice, recommendation, specification or information is accurate and correct, it cannot – because it has not direct or continuous control over where or how its products are applied – accept any liability either directly or indirectly arising from the use of its products, whether or not in accordance with any advice, specification, recommendation or information given by it.



Innova House, Innova Science Park, 4 Kinetic Crescent, Enfield, EN3 7XH, UK.

t: +44 (0)20 8344 8210 f: +44 (0)20 8344 8211 e: info@ritec.co.uk w: www.ritec.co.uk

